

# Castle Care-Tech Ltd.

## Omega *petite* Alarm System Operating Instructions

### ADDENDUM FOR USE WITH OMEGA 5e CONTROLS

Please note the following variations from the printed Omega *petite* instruction manual for use with the Omega 5e Control Panel:

#### **1.3 Fault Warning During Exit:**

Special care should be taken to ensure that detectors not forming part of the 'exit route' are clear before attempting to set the system.

#### **4.4 Changing Your Access Code:**

The facility for the user to change the access codes has NOT yet been implemented in the Omega 5e. Please arrange with your installing company for any necessary changes.

#### **6.2 Indications:**

Additional indications on the Omega 5e are:

'0 - 4' flashing Tamper alarm on zone indicated.